

	SPARE PART LIST	
S.No	Item Discription	Price
1	MAIN PCB CARD HUPS 650VA/700VA	1450
2	MAIN PCB CARD HUPS 850VA/900VA	1450
3	MAIN PCB CARD HUPS 1050VA/1100VA	1600
4	MAIN PCB CARD HUPS 14SOVA/1600VA 24V Solar	1900
5	MAIN PCB CARD HUPS 2000VA/2100VA	2600
6	MAIN PCB CARD HUPS 2.5KVA 48V	5800
7	MAIN PCB CARD HUPS 3.5KVA 48V	6200
8	MAIN PCB CARD HUPS 5KVA 48V	9500
9	MAIN PCB CARD HUPS 5KVA 96V	9500
10	MAIN PCB CARD HUPS 7.5KVA 120V	10200
11	MOTHER CARD HKVA UPS SP-UT(CASE CAR)	3500
12	Driver Card LKVA	225
13	Driver Card 1400VA	450
14	Mosfet 90NF	35
15	ControlCard 650VA	410
16	ControlCard 8SOVA	410
17	ControlCard 14SOVA	410
18	ControlCard 1050VA	410
19	ControlCard 2000VA	590
20	ControlCard 2.5KVA 48V	590
21	ControlCard 3.5KVA 48V	590
22	ControlCard 5KVA 48V	750
23	ControlCard 5KVA 96V	750
24	IGBT Driver Card	500
25	TRANSFORMER (400/ 23-0-23)	90
26	SCR Driver Card	450
27	LCD 16*2	350
28	LCD Harness	55
29	12V Soalr Charge Controller	850
30	24V Solar Charge Contoller	1250
31	48V Soalr Charge Controller	2500
32	96V Soalr Charge Controller	4500
33	Soalr Controller Card (HKVA)	750
34	ON /OFF Switch PCB.	150
35	12V DC Fan	85
36	LCD LKVA.	350